



NUMBER: 19-008-05

GROUP: Steering

DATE: October 26, 2005

This bulletin is supplied as technical information only and is not an authorization for repair. No part of this publication may be reproduced, stored in a retrieval system, or transmitted, in any form or by any means, electronic, mechanical, photocopying, or otherwise, without written permission of DaimlerChrysler Corporation.

SUBJECT:

Revised Power Steering System Bleeding Procedures

MODELS:

2004 - 2006	(CS)	Pacifica
2002 - 2006	(DR/DH/D1)	Ram Pickup
2004 - 2006	(HB)	Durango
2001 - 2006	(JR)	Sebring Convertible/Sebring Sedan/Stratus Sedan
2002 - 2006	(KJ)	Liberty
2005 - 2006	(LX/LE)	300/Charger/Magnum
2005 - 2006	(ND)	Dakota
2000 - 2005	(PL)	Neon/SRT4
2001 - 2006	(PT)	PT Cruiser
2001 - 2006	(RG)	Chrysler Voyager (International Markets)
2001 - 2006	(RS)	Town & Country/Caravan/Voyager
2005 - 2006	(WK/WH)	Grand Cherokee
2006	(XK/XH)	Commander

NOTE: This bulletin does NOT apply to DR SRT-10 vehicles.

SPECIAL TOOLS/EQUIPMENT REQUIRED:

9688	Adapter, P/S Cap
C-4207-A	Vacuum Pump, Hand (or equivalent)

POWER STEERING SYSTEM BLEEDING PROCEDURE:

WARNING:The fluid level should be checked with engine off to prevent injury from moving components.



CAUTION: MOPAR® Power Steering Fluid +4 or ATF+4 (MS-9602) is to be used in the power steering system. No other power steering or automatic transmission fluid is to be used in the system. Damage may result to the power steering pump and system if any other fluid is used. Do not overfill the power steering reservoir.

CAUTION: If the air is not purged from the power steering system correctly, pump failure could result.

NOTE: If the power steering reservoir cap does not contain a dipstick, the reservoir has a level indicator and a window to observe fluid level.

NOTE: Be sure the vacuum tool used in the following procedure is clean and free of any fluids.

1. Wipe the filler cap clean and fill the power steering reservoir to the proper level. The dipstick should indicate COLD when the fluid is at normal ambient temperature.
2. Tightly insert Miller Special Tool, 9688 - P/S Cap Adapter, onto the pump reservoir (Fig. 1).




Fig. 1 VACUUM PUMP

- 1 - HAND VACUUM PUMP C-4207-A
- 2 - CLEAR HOSE FROM ADAPTER TO RESERVOIR
- 3 - SPECIAL TOOL - 9688
- 4 - VACUUM PUMP RESERVOIR

CAUTION: Failure to properly connect the vacuum pump reservoir may allow power steering fluid to be sucked into the vacuum pump.

CAUTION: Do not run the engine while vacuum is applied to the power steering system.

NOTE: When performing [Step #3](#), make sure the minimum vacuum level is maintained during the entire time period.

3. Using a hand vacuum pump, Miller Special Tool C-4207-A, with the vacuum reservoir attached, apply 68-85 kPa (20-25 in. Hg) of vacuum to the power steering system for a minimum of 3 minutes.
4. Slowly release the vacuum, remove the special tools and add fluid to the proper level if necessary.
5. Repeat [Step #1](#) through [Step #4](#) until the fluid level no longer drops.
6. Start the engine and cycle the steering wheel from lock to lock three times.

NOTE: Do not hold the steering wheel on stops.

7. Stop the engine and check for leaks at all connections. Check for any signs of air in the reservoir and check reservoir level. If air is present repeat the procedure if necessary.

POLICY:

Information Only.